

Baby Butter Beans



Ingredients

3 c SWP Baby Butter Beans
1 T bacon fat
2 t salt
1/2 t pepper

Directions

1. Place beans in pot and fill with water. Bring to a boil over medium to medium-high heat.
2. Add bacon fat, salt, and pepper and stir. Reduce heat, cover with lid, and simmer beans for about 15-20 minutes.